


MODEL : PUK65



SPARE PARTS LIST

NO : MF-1107

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Cylinder head	3101055	3	21	Hexagon bolt	2B00-SM08*020	4
2	Allen bolt set	3B01-M06*040V	12	22	Breathing cover	2321008	1
3	In. & Ex. valve assembly	3B13-AC0765C	2	23	Oil seal	2N50-TC24*47*07	1
4	Double head screw	3B11-001-A	12	24	Pulley	3PBF-105A224	1
5	Cylinder	3201035	3	25	Plate washer	2B30-08*35*35	1
6	Cylinder gasket	2G04-003	3	26	Hexagon bolt set	3B00-SM08*035AV	1
7	Piston ring set	3B32-65N	3	27	Air filter set	2140020A	2
8	Piston set	3B31-65N	3	28	Filter element	2142013	2
9	Rod set	3B33-H2048	2	29	Exhaust elbow	2N06-04T04HSS	1
10	Rod set	3B33-H2037	1	30	Exhaust 3-way pipe	2N09-04H04T04H4	1
11	Crankcase	3301140	1	31	Exhaust 3-way pipe	2N09-04H04T04H2	1
12	Oil draining plug	2N33-002	1	32	Unloading tube set	3B2-02*395N	2
13	Oil sight gauge set	2303022B	1	33	Exhaust tube set	3B2-04*195	2
14	Oil filling plug set	2319003A	1	34	Unloading spring	2S03-001	3
15	Bearing	2N35-6205	1	35	O-ring	2N52-P06V	3
16	Crankshaft & balancer	3304046	1	36	Unloading piston	2113006	2
17	Pulley key	2N47-63*09	1	37	O-ring	2N52-P16*3V	3
18	Bearing	2N35-6205Z	1	38	Unloading nut	2B26-001	3
19	Bearing seat gasket	2G06-008	1	39	Unloading elbow	2N06-01T02H	1
20	Bearing seat	3311036	1	40	Unloading 3-way pipe	2N09-02H01T02H4	2