


MODEL : FUK20



SPARE PARTS LIST

NO: MF-1707

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Cylinder head	3101022	1	20	Bolt	2B02-FM5*010WB	4
2	Allen bolt set	3B01-M06*040V	4	21	Radiation fan cover	2337002	1
3	Exhaust elbow	2N06-04T04H	1	22	Oil seal	2N50-TC20*40*07	2
4	Air filter set	2140019	1	23	Bearing	2N35-6204Z	2
5	Filter sieve	2142013	1	24	Crankshaft & balancer	3304042	1
6	In. & Ex. valve assembly	3B13-AC0765C	1	25	Rear bearing seat gasket	2G06-008	1
7	Cylinder	3201035G	1	26	Rear bearing seat	3311013	1
8	Double head screw set	3B11-001-A	4	27	Breathing cover	2321002	1
9	Cylinder packing	2G04-003	1	28	Hexagon bolt	2B00-SM08*020	4
10	Piston ring set	3B32-65N	1	29	Pulley	3PBA-105A124	1
11	Piston set	3B31-65N	1	30	Plate washer	2B30-08*35*35	1
12	Radiation fan	2336001	1	31	Hexagon bolt set	3B00-SM08*035AV	1
13	Rod	2315028	1	32	Unloading spring	2S03-001	1
14	Oil splasher	2317013	1	33	O-ring	2N52-P06V	1
15	Bolt	2B02-FM5*010	1	34	Unloading piston	2113007	1
16	Crankcase	3301009	1	35	O-ring	2N52-P16*3V	1
17	Oil draining plug	2N33-001	1	36	Unloading nut	2B26-001	1
18	Oil draining tube	2305002	1	37	Unloading elbow	2N06-01T02H	1
19	Dipstick set	2339007A	1				