


# MODEL : GUK200



## SPARE PARTS LIST

NO:MF-1707

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Cylinder head	3101054	3	28	Breathing cover	2321008	1
2	Allen bolt set	3B01-M12*045V	18	29	Oil filling plug set	2319004A	1
3	Air filter	2140011	3	30	Bearing	2N35-32210	2
4	Filter element	2142009	3	31	Crankshaft & balancer set	3304151	1
5	Exhaust tank gasket	2G09-004H	3	32	Pulley key	2N47-10*8*45	1
6	Exhaust tank	3127001	2	33	Rear bearing seat gasket	2G06-020	1
7	Plug	2B14-ST06E	2	34	Rear bearing seat	3311029	1
8	Hexagon bolt set	3B00-SM10*075V	12	35	Oil seal	2N50-TC50*72*12	1
9	Nipple	2N01-009	11	36	Pulley	3PBF-138B450	1
10	Exhaust tank	3127002	1	37	Fly wheel	3PBF-630*280	1
11	Cylinder head gasket	2G01-020C	3	38	Hexagon bolt set	3B00-SM08*035AV	6
12	Double head bolt set	3B11-005-A	12	39	Pulley washer	2B34-13*95*12	1
13	Cylinder	3201044	3	40	Hexagon bolt set	3B00-SM12*050V	1
14	Cylinder gasket	2G04-008	3	41	Unloading tube set	3B2-02*630N	2
15	Piston ring set	3B32-120N	3	42	Inlet&Exhaust washer	2B32-004	6
16	Piston set	3B31-120NP	3	43	Inlet valve assembly	3B12-NUK150A	3
17	Rod set	3B33-NP150B	2	44	O-Ring	2N52-G65V	6
18	Rod bush(2 pieces)	2316007-B	3	45	Inlet press plate	3103002	3
19	Rod set	3B33-GK200A	1	46	Exhaust valve assembly	3B11-NK150A	3
20	Crankcase	3301137	1	47	Exhaust press plate	3126009	3
21	Oil draining plug	2N33-003	1	48	Hexagon bolt set	3B00-SM08*030V	24
22	Thrust block	3312008-A	1	49	Exhaust tube set	3B2-06*260	2
23	Oil sight gauge set	2303024B	1	50	Exhaust tube set	3B2-06*205	2
24	Front bearing seat gasket	2G05-009	1	51	O-ring	2N52-P22AV	3
25	Front bearing seat	3309042	1	52	Unloading piston	2113008	3
26	Bolt set	3B07-SM16*40-A	1	53	Unloading elbow	2N06-01T02H	1
27	Hexagon bolt	2B00-SM10*025	12	54	Unloading 3-way pipe	2N09-02H01T02H4	2