


# MODEL :HUL70



## SPARE PARTS LIST

NO : MF-1707

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Cylinder head	3101062A	2	21	Front bearing seat gasket	2G05-010	1
2	Allen bolt set	3B01-M08*055V	8	22	Bearing	2N35-6206	2
3	Allen bolt set	3B01-M08*065V	4	23	Crankshafe & balancer	3304072	1
4	Air filter set	2140019A	2	24	Rear bearing seat gasket	2G06-017	1
5	Filter element	2142013	2	25	Rear bearing seat	3311027	1
6	Unloading tube	3B2-02*170N	2	26	Oil seal	2N50-TC30*50*11	1
7	Exhaust elbow	2N06-04T04H	1	27	Pulley	3PBF-145A230M	1
8	In. & Ex. valve seat assembly	3B13-AH30	2	28	Pulley washer	2B34-13*52*14	1
9	Double head bolt set	3B11-001-A	12	29	Hexagon bolt set	3B00-SM12*050V	1
10	Cylinder	3201047	2	30	Unloading 3-way pipe	2N09-02H01T02H1	3
11	Cylinder gasket	2G04-017	2	31	Unloading tube set	3B2-02*430N	1
12	Piston ring set	3B32-651N	4	32	Unloading spring	2S03-001	4
13	Piston set	3B31-652	4	33	O-ring	2N52-P06V	4
14	Rod set	3B33-HL60	4	34	Unloading piston	2113007	4
15	Crankcase	3301108	1	35	O-ring	2N52-P16*3V	4
16	Oil draining plug	2N33-002	1	36	Unloading nut	2B26-001	4
17	Oil sight gauge set	2303022B	1	37	Unloading elbow	2N06-01T02H	1
18	Breather set	2339009A	1	38	Exhaust 3-way pipe	2N09-04H04T06H2	1
19	Hexagon head bolt	2B00-SM08*020	10	39	Exhaust tube set	3B02-04*680	1
20	Front bearing set	3309029	1				