


MODEL : PL20



SPARE PARTS LIST

NO : MF-1010

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Cylinder head	3101042	1	15	Bearing	2N35-6204Z	1
2	Allen bolt set	3B01-M06*040V	4	16	Rear bearing seat gasket	2G06-008	1
3	In. & Ex. valve assembly	3B13-AC0751	1	17	Rear bearing seat	3311013	1
4	Double head screw set	3B11-001-A	4	18	Breathing cover	2321002	1
5	Cylinder	3201036	1	19	Hexagon bolt	2B00-SM08*020	4
6	Cylinder gasket	2G04-002	1	20	Oil seal	2N50-TC20*40*07	1
7	Piston ring set	3B32-51N	1	21	Pulley	3PBF-105A120	1
8	Piston set	3B31-51N	1	22	Plate washer	2B30-08*35*35	1
9	Rod set	3B33-H1022	1	23	Hexagon bolt set	3B00-SM08*035AV	1
10	Crankcase	3301012	1	24	Exhaust elbow	2N06-04T04H02T	1
11	Oil draining plug	2N33-001	1	25	Air filter set	2140019A	1
12	Oil filling plug set	2339007A	1	26	Filter element	2142013	1
13	Bearing	2N35-6204	1	27	Oil draining plug	2N33-002	1
14	Crankshaft & balancer	3304041	1				