


MODEL : PUP20



SPARE PARTS LIST

NO : MF-1707

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Cylinder head	3B1-PU21	2	17	Rear bearing seat gasket	2G06-008	1
2	Hexagon bolt set	3B00-SM08*050V	8	18	Oil seal	2N50-TC24*47*07	1
3	Cylinder head gasket	2G01-006C	2	19	Rear bearing seat	3311034	1
4	Double head screw set	3B11-001-A	8	20	Breathing cover	2321008	1
5	Cylinder	3201038	2	21	Hexagon blot	2B00-SM08*020	4
6	Cylinder gasket	2G04-003	2	22	Pulley	3PBF-105A124	1
7	Piston ring set	3B32-65N	2	23	Plate washer	2B30-08*35*35	1
8	Piston set	3B31-65N	2	24	Hexagon bolt set	3B00-SM08*035AV	1
9	Rod set	3B33-H20601	2	25	Exhaust elbow	2N06-04T04H	1
10	Crankcase	3301015	1	26	Exhaust three way pipe	2N09-04H04T04H1C	1
11	Oil draining plug	2N33-001	1	27	Exhaust tube set	3B2-04*215	1
12	Oil sight gauge set	2303022B	1	28	Air filter set	2140019A	2
13	Oil filling plug set	2319003A	1	29	Filter element	2142013	2
14	Bearing	2N35-6204	1	30	Unloading elbow	2N06-01T02H	1
15	Crankshaft & balancer	3304038	1	31	Unloading three way pipe	2N09-02H01T02H4	1
16	Bearing	2N35-6205Z	1	32	Unloading tube set	3B2-02*450N	1