


# MODEL : TUK50(SILENT)



## SPARE PARTS LIST

NO: MF-1707

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Cylinder head	3101048	2	32	Exhaust tube set	3B2-06*215	1
2	Allen bolt set	3B01-M10*055V	8	33	Exhaust tube set	3B2-06*490	1
3	Cylinder head gasket	2G01-007C	2	34	Cylinder head	3101056	1
4	Double head bolt set	3B11-003-A	12	35	Allen bolt set	3B01-M06*040V	4
5	Cylinder	3201015	2	36	In. & Ex. valve assembly set	3B13-AC0765C	1
6	Cylinder gasket	2G04-009	3	37	Cylinder	3201029	1
7	Piston ring set	3B32-80N	2	38	Piston ring set	3B32-65N	1
8	Piston set	3B31-80L	2	39	Piston set	3B31-T65	1
9	Rod set	3B33-P2346	1	40	Rod set	3B33-T5048	1
10	Rod bush	2316001	6	41	Exhaust elbow	2N06-06T06T85	1
11	Rod set	3B33-P2337	1	42	Spare tank	3125001CS	1
12	Crankcase	3301017	1	43	Pressure relief valve	2406020A	1
13	Ball valve	2413010	1	44	Inlet/Exhaust washer	2B31-001	4
14	Oil sight gauge set	2303022B	1	45	Inlet valve assembly	3B12-PU23	2
15	Oil filling plug set	2319004A	1	46	Unloading piston	2113009	2
16	Bearing	2N35-6306	2	47	O-ring	2N52-P18V	2
17	Crankshaft & balancer	3304025	1	48	Inlet valve holder	3110008	2
18	Pulley key	2N47-63*09	1	49	Exhaust valve assembly	3B11-NPP23	2
19	Rear bearing seat gasket	2G06-002	1	50	O-Ring	2N52-G45V	2
20	Oil mesh	2352002	1	51	Exhaust press plate	3126004	2
21	Rear bearing seat	3311003	1	52	Hexagon bolt set	3B00-SM08*030V	8
22	Breathing cover	2321008	1	53	Unloading elbow	2N06-01T02H	1
23	Hexagon bolt	2B00-SM10*025	6	54	Unloading 3-way pipe	2N09-02H01T02H4	2
24	Oil seal	2N50-TC30*50*11	1	55	Unloading spring	2S03-001	1
25	Pulley	3PBF-145A230B	1	56	O-ring	2N52-P06V	1
26	Pulley washer	2B34-13*52*14	1	57	Unloading piston	2113015	1
27	Hexagon bolt set	3B00-SM12*050V	1	58	O-ring	2N52-P16*3V	1
28	Air filter set	2140003	2	59	Unloading nut	2B26-003	1
29	Filter element	2142002	2	60	Unloading tube set	3B2-02*430N	2
30	Exhaust elbow	2N06-06T06H	3	61	O-ring	2N52-PO9V	1
31	Exhaust 3-way pipe	2N09-06H06T06H2	1	62	Low oil switch set	3353105	1